

RTM Software

Roxtec Transit Manager



Roxtec Transit Manager



A cost-reducing software
for easy planning of cable and pipe transits

We Seal Your World™

For easy planning of cable and pipe transits

The software Roxtec Transit Manager, RTM, has several features that simplify the design, planning and installation of cable and pipe transits.

The RTM Software is developed for design departments using Roxtec products. Designing transits with CAD programs can be time-consuming, but the RTM Software allows you to cut corners through auto-planning and save time in all phases.

Easier planning


RTM has a large database containing all standard products, modern user interface and a Custom Frame Designer as well as import and export routines. You can enter cables manually or import project data from external lists to generate automatic packing plans. Then you can print the materials list for the purchasing department.

Weight calculation

With the RTM Software, you can also calculate the weight of transits, include wedge kits and change data for cables belonging to several transits. The plans can be exported as DXF files, and the created geometries imported in CAD programs.

Installation aid

The transit plans allow each transit to be documented, identified and labeled. Every frame opening is shown as a picture for easy understanding. Packing plans can be handed to the installers for




safe installation. The packing plans and the materials list minimize the risk for error and clearly simplify logistics: only the right products are brought on site.

System recommendations

- Windows XP/Vista/Windows 7
- 2 GHz processor
- 256 MB RAM
- 150 MB of hard drive space for program installation

The RTM Software is a client-server solution. It can be installed locally or in a network of computers.



RTM SOFTWARE 3.0 FEATURES

- Import external cable lists
- Generate automatic packing plans
- Customize project criteria
- Generate CAD drawings
- Inquiry list for ordering

How to order:

If you want to order the RTM Software, please contact your local Roxtec sales representative.



Roxtec International AB
 Box 540, 371 23 Karlskrona, SWEDEN
 PHONE +46 455 36 67 00, FAX +46 455 820 12
 EMAIL info@roxtec.com, www.roxtec.com